

# Ghee's®

**Must Purchase Pattern #791  
Roundabout Bag**

## ***Roundabout Additions for a CD Case with Inserts***

The small size of the Roundabout Handbag #791 is ideal for making a CD Case. With a few changes to the pattern, it's easy to make the Roundabout a more versatile pattern.

Extra notions:

20-inch zipper for opening

9-inch zipper for outside pocket



Order other handbag patterns and hardware or accessories from:

## ***Ghee's***

P.O. Box 4424 Shreveport, LA 71134

(318) 226-1701 • FAX: (318) 226-1781 • [www.ghees.com](http://www.ghees.com)

©Copyright 2006. All rights reserved. Ghee's patterns are created for your personal use to showcase your own fabric manipulations and embellishments. Please remember that this material is copyrighted. No portion of this pattern may be reprinted without the written permission of Ghee's.




**Ghee's**  
www.ghees.com

**#791**

**7**

Fold



# CD ZIPPER SECTION

- Cut 1 — Fashion Fabric
- Cut 1 — Fleece
- Cut 1 — Fusible Web
- Cut 1 — Lining

CUTTING LINE FOR  
ZIPPER REPLACEMENT

STITCHING LINE

CUTTING LINE

1/2 INCH SEAM ALLOWANCE

**Ghee's**

P.O. Box 4424 Shreveport, LA 71134

(318) 226-1701 • FAX: (318) 226-1781 • www.ghees.com

## Instructions

The zipper section #2 of the original pattern is too short to open wide enough for the CD Inserts. Use pattern piece #7 for the zipper section and pattern piece #8 for the gusset rather than #3. Follow the instructions in the pattern using Steps 10-12 to insert the lined zipper. Use a 20-inch zipper for the CD case and trim the excess once the zipper is inserted in the fabric.

Make the strap shorter to use as a hand held strap rather than shoulder strap, or eliminate the strap altogether.

The inside zipper Patch Pocket is not appropriate for the inside of the CD Case, as the slider and zipper coils could scratch the CDs. However, the pocket could be placed on the outside of the bag to hold dongles or ear pieces. Another option is to make a Zipper Pocket as shown in Step 20.

Use a narrow strip of hook and loop (Velcro®) stitched to the gusset to hold the CD insert in place. This offers the option to add or remove multiple inserts when desired.

**Ghee's**  
www.ghees.com

**#791**

**8**

# CD GUSSET

- Cut 1 — Fashion Fabric
- Cut 1 — Fleece
- Cut 1 — Fusible Web
- Cut 1 — Lining

STITCHING LINE

CUTTING LINE